

install guide

40L slim plastic step can lid replacement




Lid assembly PD0278, PD0279, PD0280
for CW1361, CW1362, CW1363, CW1393, CW1395
40L slim plastic step can




video guide

Removing lid

1. Disconnect hinges. Unsnap one side at a time.



2. Remove lid from vertical rod.



Installing lid

1. Insert vertical rod into middle portion on lid.



2. Gently close the lid. Make sure hinges on lid and can are properly aligned. **Tip:** Press on lock to ensure lid is secured to body of can.



3. Hold front of can down near silver lock and push down on one hinge until it snaps into place. Snap other hinge into place.



Final Result



product questions or returns
customer.support@simplehuman.com